




# Vivitar Vivicam T027 Power Button Replacement

Replace the power button of the Vivitar Vivicam T027 digital camera.

Written By: Dana



## INTRODUCTION

If the power button breaks or gets jammed, you may need to replace it.

---



### TOOLS:

- [Tweezers](#) (1)
  - [Soldering Station](#) (1)
  - [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Power Button



- Remove the 3 mm screws at the sides of the camera using a Phillips #00 screwdriver.


## Step 2



- Remove sticker on top of camera as it covers a screw.
- ⓘ There should be 5 screws on the sides of the camera to remove in total.




## Step 3




- Separate the front piece of the camera from the back, revealing the motherboard.

## Step 4



- Take tweezers and remove the black plastic cover off the power button.

## Step 5



- Using a soldering kit, remove the black and red wire from the silver power button.

⚠ Be cautious of the heat from the soldering kit as to not burn yourself.

- Reference [this guide](#) for assistance!

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-20 04:07:29 AM.